


Assembly Instructions

Sensor Towel Dispenser


Sensor Handtuch Spender Sensor Handdoekroldispenser Distributeur Sensor essuie-mains Dozownik do ręczników z czujnikiem Sensor









Tools required





Suitable for






hang and fix (inside)

Item No.: **331070**

Sensor Towel Dispenser







Item No.: **331070**

Sensor Towel Dispenser







BATTERY LEVEL

Red Flashing = Please replace the batteries.



1 second (White LED) 3 seconds (Green LED) 5 seconds (Blue LED)

TIMER



PAPER LENGTH

Adjust the paper length from 20 cm (White LED) 25 cm (Green LED) 30 cm (Blue LED) 34 cm (Purple LED)



Paper feed when threading the paper

PAPER FEED





Adjust the "sheet feeding" between on demand or



AUTO

